


## **Software and Printer Support**

## The TTM430 / TTM460 shows a ribbon error.



New TTM430 Series & TTM460 Series

OPTION 1: Click the Windows Start button and select Devices and Printers. Right-click your printer's driver and select Printing Preferences. Click the Advanced Setup tab. Under Settings, uncheck "thermal transfer." Try printing to see if the issue is resolved.



- 2 OPTION 2: On the front panel of the printer, turn **Ribbon Supply** OFF. Try printing to see if the issue is resolved.
- 3 If the problem still exists, please contact **Tech Support** for possible repair.

